

gridBox commissioning - Quick guide


This brief installation instruction provides a quick overview of all the necessary steps. Detailed information on the individual steps, references, and sources can be found in our [HelpCenter](#). The Installation instructions are only valid for the integration of the energy management system and the configuration of relevant assets.

Commissioning the components

1. Install, switch on, and update the inverter, charging station, heat pump, etc.
2. Configure all the above components for the gridBox. (See short instructions)


Installing the gridBox

Connect the box to the socket using the mains plug and connect it to the WLAN router or switch using the Ethernet cable.



Commissioning the gridBox

1. Open the app and create a customer account under *Register now*.
2. Enter the start code from the packaging box.
3. Fill in personal data and system overview.




4. Check the device scan in the System setup step.



IMPORTANT

Select a meter as the grid connection point.

5. Configuring and activating energy management.



6. Click on Go to complete the setup and perform the final check.

- All devices are displayed
- All devices display energy flows